

# 利刃R3手摇磨豆机-90×140mm-风琴折

90mm
80mm

### 产品说明书

MHW-3BOMBER 利刃R3 pro手摇磨豆机

### 产品部件及配件

- 利刃R3 pro手摇磨豆机×1
- 粉仓盖×1
- 防尘圈×1
- 毛刷×1
- 筛网×1
- 说明书×1

### 部件介绍

- 手柄
- 顶盖
- 摇杆
- 螺丝
- 调节环
- 螺母
- 卡簧
- 轴承
- 机身
- 中轴
- 垫片
- 弹簧
- 力盘托架
- 外刀盘
- Rapidity磨芯
- 筛网
- 储粉仓
- 底盖

### 使用方法

- 打开顶盖
- 双手持握, 按箭头方向调整研磨度
- 放入适量咖啡豆 (15-20g)
- 开始研磨
- 取下储粉仓
- 装上粉仓盖, 左右晃动弹出咖啡粉

\*根据个人使用需求, 取用相应的筛网, 手冲咖啡建议使用500um筛网

### RAPIDITY-3镀钛磨芯

利刃R3配备了自主研发的Rapidity-3镀钛磨芯45°的七星芯刃, 70°的棱形芯刃 (磨芯硬度HRC55-60°) 在高效研磨时更省力也有助于减少细粉率

### 注意事项

- 本产品仅为研磨烘焙后的咖啡豆, 请勿研磨其他物品;
- 使用后请及时清理储粉仓, 在储粉仓有粉的情况下, 请勿更换筛网;
- 建议用气吹, 毛刷清理磨豆机, 请勿水洗;
- 粉仓有粉的情况下, 请勿打开顶盖;
- 请以包装内实物为准, 当产品规格、配件、设计变更时, 本品牌不再另行通知;
- 不建议自行改装, 拆卸, 更换磨芯, 如有需求请联系客服;
- 请妥善保管本使用说明书, 以备日后查阅。

### 售后保修卡

感谢您购买MHW-3BOMBER品牌产品, 产品如无私自拆卸或人为损伤, 凭此保修卡可享受自购买日起为期1年的免费维修服务。

#### 保修条例

以下情况不属于免费保修范围:

- 未按说明书规定操作, 维护, 保管, 自行拆卸等人为因素造成的损坏;
- 使用不当, 意外原因(摔落等)造成的损坏;
- 因不可抗力因素(如雷电, 地震, 火灾, 水灾等)造成损坏。

#### 维护信息

产品名称及型号: \_\_\_\_\_  
 购买时间: \_\_\_\_\_  
 购买方式: \_\_\_\_\_  
 订单编号: \_\_\_\_\_  
 客户姓名: \_\_\_\_\_  
 联系方式: \_\_\_\_\_  
 退货原因: \_\_\_\_\_

#### 售后登记

维修  保养  退货

#### 合格证

本产品经检验符合质量标准要求 检验员:

### 维修记录

修理日期	故障情况	维修结果

#### 关于我们

MHW-3BOMBER磨炸机品牌自诞生起, 持续专注精品咖啡器具, 在坚守品质的同时传承传统, 用突破性的产品设计重新定义咖啡美学。

#### 如有任何疑问请与我们联系

☎ 磨炸机咖啡设备制造(中山)有限公司  
 @ 中山市阜沙镇东涌街1号B幢第8层第一卡  
 ☎ 400-9922-092  
 @ WWW.MHW3BOMBER.COM

官方微信: @MHW\_3BOMBER  
 官方微博: @MHW\_3BOMBER

140mm

90mm
80mm

### INSTRUCTIONS

MHW-3BOMBER Blade R3 pro Manual Grinder

### COMPONENTS AND ACCESSORIES

- Blade R3 pro Manual Grinder×1
- antislid ring×1
- Sieve×5
- Powder Bin Cover×1
- Brush×1
- Instruction Manual×1

### PRODUCT STRUCTURE

- Handle
- Top Cover
- Screw
- Nut
- Bearing
- Adjustment Ring
- Clirclip
- Body
- Central Shaft
- Gasket
- Spring
- Outer Burr
- Rapidity Grinding Core
- Screen Mesh
- Bottom Cover
- Coffee Powder Container

### HOW TO USE

- Take down the handle
- Hold with both hands and adjust the grind in the direction of the arrow
- Pour coffee beans in (15-20g)
- Start grinding
- Take down the powder container
- Close the top, Shake it from side to side to separate the fine powder

\*Choose the privilege screen based on your needs, a 500um screen is advised for pour over coffee.

### RAPIDITY-3 TITANIUM-PLATED GRINDING BURR

The Blade R3 pro Manual Grinder has a self-developed Rapidity-3 Titanium-Plated Grinding Burr 45° Seven-Star Core Blade, 70° Prismatic Core Blade (core hardness HRC55-60°) Sieves effort during efficient grinding Also helps to reduce the fine powder ratio

### HOW TO LOAD THE SIEVES

- Take out the powder container and unscrew the bottom lid
- Choose the sieve based on what you need
- Attach the sieve and screw on the bottom cover

\*When grinding espresso powder, please remove the sieve before.

### GRINDING DEGREE RECOMMENDATION

Espresso Recommend 0-20  
 Moka Pot Recommend 30-40  
 Pour Over/Drip Pot Recommend 60-80  
 cold brew coffee/French Press Recommend 90-100

### CAUTION

- This product is only designed to grind roasted coffee beans, please do not grind other material;
- Please clean the powder container in time after use, and do not replace the sieves when there is powder in the bin;
- Recommended to clean the with air blaster, brush, please do not wash it with water;
- When powder is within the fine powder container, do not open it;
- Please refer to the object in received package, when the product specifications, accessories and design are changed, we will not be subject to further notice;
- It is not recommended to modify, disassemble and replace the grinding core by yourself, please contact customer service when you need;
- Please keep this manual for future reference.

### PARAMETERS

Brand	MHW-3BOMBER
Name	Blade R3 pro Manual Grinder
Operation Mode	Manual
Capacity	Approx. 20g
Size	185×195mm, Φ53mm
Weight	Approx. 725g
Material	SUS304, SUS420, Aluminum Alloy, Walnut/Mopke, Silicone,Magnet

### WARRANTY CARD

Thanks For Purchasing MHW-3BOMBER Products. With This Warranty Card, You Can Enjoy Free Maintenance Service For 1 Year From The Date Of Purchase If The Product Is Not Disassembled Or Damaged Artificially.

#### WARRANTY RULES

The Following Conditions Do Not Belong To The Scope Of Free Warranty:

- Damage Caused By Human Factors Such As Operation, Maintenance, Storage and Self-disassembly Not In Accordance With The Instruction;
- Damage Caused By Improper Operations Or Accidents ( Falling, Etc. );
- Damage Caused By Force Majeure Factors (Such As Lightning, Earthquake, Fire, Flood, Etc.).

#### MAINTENANCE INFORMATION

Product name and model: \_\_\_\_\_  
 Purchase time: \_\_\_\_\_  
 Purchase methods: \_\_\_\_\_  
 Order number: \_\_\_\_\_  
 Customer name: \_\_\_\_\_  
 Customer contact information: \_\_\_\_\_  
 Return reason: \_\_\_\_\_

#### AFTERMARKET

Maintain  Barter  Returns

#### CERTIFICATION

THIS DEVICE MEETS QUALITY STANDARDS ACCORDINGLY  
 TEL: 400-9922-092 QC:

### MAINTENANCE RECORD

Maintenance date	Fault condition	Maintenance results

#### ABOUT US

Since our inception, MHW-3BOMBER has continuously focused on specialty coffee wares. While maintaining high quality, We have revolutionized traditional concepts by redefining Coffee aesthetics through innovative product designs.

#### IF YOU HAVE ANY QUESTIONS, PLEASE CONTACT US

☎ Bomber Coffee Equipment Manufacturing (Zhongshan) Co., Ltd  
 @ Unit 1, 8th Floor, Building B, No. 1 Jintian Street, Fusha Town, Zhongshan City  
 @ WWW.MHW3BOMBER.COM

官方微信: @MHW\_3BOMBER  
 官方微博: @MHW\_3BOMBER

140mm